


## T590 | Loaders

1782.0 mm

# Specifications

### **Dimensions**

(Q\*) Width over tracks, 400 mm tracks



(A)	Operating height	3901.0 mm
(B)	Height with operator cab	1972.0 mm
(C)	Angle of departure	27.8°
(D)	Ground clearance	188.0 mm
(E)	Ground contact length	1402.0 mm
(F)	Length without attachment	2657.0 mm
(G)	Length with standard bucket	3378.0 mm
(H)	Rollback at ground position	30.0°
(l)	Dump height with standard bucket	2319.0 mm
(J)	Height to bucket hinge pin	3023.0 mm
(K)	Dump reach at maximum height	887.0 mm
(L)	Dump angle at maximum height	42.0°
(M)	Rollback fully raised at maximum height	97.0°
(N)	Bucket width, 68-inch	1727.0 mm
$(N^*)$	) Bucket width, 74–inch	1880.0 mm
(O)	Turning radius with standard bucket	2032.0 mm
(Q)	Width over tracks, 320 mm tracks	1702.0 mm



Machine Rating	
Lift breakout force Tilt breakout force Ground pressure Rated operating capacity (ISO 14397–1) Push force Tipping load (ISO 14397-1)	2269 daN 2179 daN 24.10 kPa 971 kg 3573 daN 2773 kg
Cycle Times	
Raise lift arms Lower lift arms Bucket rollback Bucket dump	4.0 s 2.8 s 1.7 s 2.5 s
Weights	
Operating weight Shipping weight Ground pressure	3664 kg 3283 kg 40.00 kPa
Engine	
Make / Model Compliancy Fuel Cooling Power at 2600 RPM (ISO 14396) Torque at 1800 RPM (ISO 14396) Number of cylinders Displacement Bore Stroke Lubrication Crankcase ventilation Air filter Ignition Starting aid	Bobcat 2.4L, 97/68 EC Stage V Diesel Liquid 50.7 kW 252.3 Nm 4 2392 cm³ 90.0 mm 94.0 mm Gear pump pressure Closed breathing Dry replaceable cartridge with safety element Diesel-compression Glow plugs
Electrical	
Alternator Battery Starter	90 A — open frame with internal regulator 12 V — 600 A cold cranking at -18°C — 115 min reserve capacity at 25 A 12 V GEAR TYPE 4.29 hp [3.2 kW]



### **Hydraulic System**

Pump type Engine driven, gear type

Pump capacity 64.70 L/min
Pump capacity (with high flow option) 101.10 L/min
System relief at quick couplers 23.8-24.5 MPa

Control valve Three-spool, open-centre type with float detent on lift and

electrically controlled auxiliary spool

Hydraulic filter PREMIUM GRADE, ANTIWEAR MULTIVISCOSITY ISO

V646, PETROLEUM BASED

Fluid lines SAE standard tubelines, hoses, and fittings

### **Hydraulic Cylinders**

Double-acting
69.9 mm
41.4 mm
540.0 mm
Double-acting
69.9 mm
38.1 mm
330.7 mm

### **Drive System**

Transmission Infinitely variable tandem hydrostatic piston pumps, driving

two fully reversing hydrostatic motors

Tracks 320 mm width. Tension-grease cylinder and triple-flange

spring rollers

Main drive Fully hydrostatic, rubber track drive

#### **Traction**

Tracks 320 mm wide, rubber

Max. travel speed (low range – standard) 10.4 km/h Max. travel speed (high range – optional) 16.0 km/h

#### Fluid Capacities

Cooling system with heater 10.90 L
Cooling system without heater 10.60 L
Engine oil with filter 9.20 L
Fuel tank 138.20 L
Hydraulic reservoir 7.57 L
Hydraulic / Hydrostatic system 36.00 L




### Fluid Specifications

Engine coolant

Engine oil

Hydraulic fluid

Bobcat PG Coolant
5 L can - 6904844A
25 L container - 6904844B
209 L drum - 6904844C
1000 L tank - 6904844D
Oil must meet API Service Classification of CJ-4 or better, or ACEA E9 or better.
Recommended SAE viscosity number for anticipated



\* Can be used only when available with appropriate diesel rating.

For synthetic oil use the recommendation from the oil manufacturer.

Bobcat Superior SH 5 L can - 6904842A 25 L container - 6904842B 209 L drum - 6904842C 1000 L tank - 6904842D Bobcat Bio Hydraulic 5 L can - 6904843A 25 L container - 6904843B 209 L drum - 6904843C 1000 L tank - 6904843D

temperature range.



#### **Controls**

Engine Hand throttle or optional foot accelerator pedal (SJC)
Starting Keyless start. Glow plugs automatically activated.

Front auxiliary (standard) Proporcional switch on Hand Levers or optional Selectable

Joystick Controls (SJC)

Loader hydraulics tilt and lift Foot Pedals or optional Selectable Joystick Controls (SJC)
Service brake Two independent hydrostatic systems controlled by two

hand-operated steering levers

Parking brake Mechanical disc activated by manually operated switch on

left instrument panel

Vehicle steering

Hand Levers or optional Selectable Joystick Controls (SJC)

Auxiliary pressure release

Pressure is relieved through the coupler block. Push in and

hold for 5 s.

Rear auxiliary (optional) Electrical switch on left-hand steering lever or joystick

(SJC)

#### Instrumentation

The following loader functions are monitored by a combination of gauges and warning lights in the operator's line of sight. The system alerts the operator of monitored loader malfunctions by way of audible alarm and visual warning lights.

#### Standard Instrument Panel

- · Gauges
  - Engine temperature
  - Fuel
- Indicators
  - Bobcat Interlock Control System
  - Engine preheat
  - · Two speed
  - Turn signals
- · Warning lights
  - Engine temperature
  - Fuel level
  - General warning
  - Seat belt
  - Seatbar down
  - Engine malfunction
  - Hydraulic system malfunction
  - Lift and tilt valve, hydraulics lock-out
  - Parking brake
  - Hydraulic oil temperature
  - · Engine oil pressure
  - · Hydraulic oil pressure
- Buttons
  - Work lights and road lights
  - High flow auxiliary hydraulics
  - Auxiliary hydraulics
  - Information (Hour meter, Engine RPM, Battery voltage, Service codes, Service reminder)
  - Traction lock override
  - Press to operate loader
- · Rocker switch
  - Parking brake



- Alarm
  - Beep when error, warning or shutdown condition exists

#### **Deluxe Instrument Panel**

Same gauges, warning lights and other features as Standard Instrument Panel, plus:

- Gauges
  - Engine oil pressure / temperature
  - · Hydrostatic charge pressure
  - Hydraulic oil temperature
  - Battery
- · Additional features
  - Keyless start with password capability
  - Digital clock
  - User name and hourmeter
  - Attachments control information
  - Current job hours
  - · High Flow lockouts
  - Multi-language display
  - Help screens
  - Auto Idle
  - DPF Management
  - Diagnostic capability
  - Engine/hydraulic systems shutdown function
  - Password lockout
- · Icons
  - Active warnings
  - · Vitals (Engine speed, Oil Pressure, Temperature, System voltage, Hydraulic charge pressure, Oil temperature)
  - Service
  - Main screen
  - Attachments
  - Security
  - DPF Regeneration
  - HEST Lamp
  - Inhibit DPF Regeneration
  - Forced Parked Regeneration
  - Display
- Buttons
  - · Left scroll
  - Enter
  - Right scroll

#### Serviceability

Access is available to the following through the rear door/tailgate and rear screen:

- · Air filter
- Alternator
- · Battery
- · Cooling system (engine oil and hydraulic oil coolers easily separable for cleaning)
- · Engine oil and fuel filters
- · Engine oil drain and dipstick
- Hydraulic oil fill and filter (access at the upper right side of the machine)
- Starter

Access available via the side of the machine:

Easy access to all lift arm grease points



Rod end of the tilt cylinder has a replaceable bushing
Tailgate has an optional lock for vandal-proofing
Tailgate is equipped with door-stop to hold door open while servicing
Tip-up operator cab gives access to certain hydraulic system components
Bob-Tach™ pivots have replaceable wear bushings

#### **Standard Features**

- · Bobcat Interlock Control System (BICS)
- · Parking brake
- Deluxe operator cab\* Includes interior cab foam, side, top and rear windows, Deluxe wire harness, dome light and electrical power port <sup>1</sup>
- · Noise reduction kit
- · Operating lights, front and rear
- Deluxe instrument panel
- · Keyless start with password capability
- · Suspension seat
- · Seat belt
- · Seat bar
- Hydraulic bucket positioning (including ON/OFF switch)
- Tracks rubber 320 mm
- · Spark Arrester
- Bob-Tach™ frame
- · Cushioned lift and tilt cylinders
- · Lift arm support
- · Engine/hydraulics system shutdown
- · Automatically activated glow plugs
- · Electrically activated proportional front auxiliary hydraulics
- Auxiliary hydraulics: variable flow/maximum flow
- Machine IQ (telematic)
- Manual
- · CE certification
- Warranty: 24 months or 2000 hours (whichever occurs first)

<sup>1.</sup> Roll Over Protective Structure (ROPS) – meets requirements of SAE-J1040 and ISO 3471; Falling Object Protective Structure (FOPS) - meets requirements of SAE-J1043 and ISO 3449, Level I



### **Options**

- · Factory Options
  - Deluxe pressurized cab with heating
  - Deluxe pressurized cab with HVAC
  - Selectable Joystick Controls (SJC R/C Ready)
  - Tracks rubber 400 mm
  - Cloth Suspension Seat
  - High-flow auxiliary hydraulics
  - 7-pin attachment control
  - 2 Speed
  - Power Bob-Tach™
  - Back-up alarm
  - Radio
  - Beacon
  - Work Lights LED
  - Road Option
  - Automatic Ride Control
  - Automatic Reversing Fan
  - Custom paint color (min order of 5 units)
- · Dealer Installed Options
  - · Cab enclosure kit
  - Special applications front door kit
  - 200 lbs (74.4 kg) counterweight kit
  - · Front axle counterweight kit
  - Fuel cap locking kit
  - Deluxe instrument panel
  - Replacement Bob-Tach™
  - · Fresh air heater kit
  - · Front door kit
  - · Door sensor kit
  - · Plumbing kit for fresh air heater
  - Back up alarm kit
  - FOPS kit \*\*
  - Single-point lift kit
  - Power Bob-Tach™ kit
  - Operator cab, CE, enclosure kit
  - 7-pin attachment control
  - Four-point lift kit
  - · Rear auxiliary hydraulic kit
  - Engine block heater kit
  - Road kit
  - · Bucket positioning kit
  - Keyless kit
  - Rear window wiper kit
  - 14-pin attachment control kit
  - 4-Way flasher kit
  - 80 mm Suspension seat kit
  - · Cup holder kit
  - Headlight guard kit
  - Muffler guard kit
  - Tail light guard kit



#### **Attachments**

- · Auger Accessories
- Augers
- Backhoes
- Bale Forks
- · Box Blades
- · Breaker Accessories
- Breakers
- Brushcat™ Rotary Cutters
- Brush Saws
- · Combination Buckets
- · Concrete Mixers
- Concrete Pumps
- · Construction / Industrial Buckets
- Diggers
- · Dozer Blades
- · Drop Hammers
- · Dumping Hoppers
- · Flail Cutters
- · Forestry Cutters
- · Graders
- · Grapples, Industrial
- Landplanes
- · Landscape Rakes
- · Laser Equipment
- · Low Profile Buckets
- Miscellaneous
- · Mixing Buckets
- Mowers
- Pallet Fork Accessories
- · Pallet Forks, Hydraulic

- · Planer Accessories
- Planers
- · Rear Stabilizers
- · Remote Control
- · Root Grapples
- Rotary Grinders
- · Sand Cleaners
- Scarifiers
- Scrapers
- Seeders
- Skeleton Buckets
- Snow Blades
- Snow Pushers
- Snow V-Blades
- Sod Lavers
- Soil Conditioners
- Spreader
- Spreaders
- Stump Grinders
- Sweepers
- Tillers
- Tilt-Tatch
- · Tree Transplanters
- Trench Compactors
- Trenchers
- · Utility Forks
- Utility Frames
- Vibratory Rollers
- · Wheel Saws
- · Wood Chippers

#### **Environmental**

Operator LpA (98/37 & 474-1)
Noise level LWA (EU Directive 2000/14/EC)
Whole body vibration (ISO 2631-1)
Hand-arm vibration (ISO 5349-1)

82 dB(A) 101 dB(A) 0.84 ms<sup>-2</sup> 2.29 ms<sup>-2</sup>



### Safety

Bobcat Interlock Control System (BICS), standard

Lift arm bypass control, standard

Seat belt, standard

Seat bar, standard Operator cab, standard

Lift arm support, standard Parking brake, standard Grab handles, standard Safety tread, standard

Attachment steps, standard Rear window, standard Front and rear work lights, standard Back-up alarm, optional Lift kits, optional

Special applications kit, optional Operator handbook, standard

Requires the operator to be seated in the loader with the seat bar in place and the engine running. After the operator presses the "Press to Operate Loader" button, the loader's hydraulic lift and tilt functions and traction drive can be operated.

Used to lower the lift arms in the event that the lift arms cannot be lowered during normal operating conditions. Should always be worn when operating the loader. Three-point shoulder belt provides restraint for high range speeds.

Secondary operator restraint, also serves as an arm rest. An enclosed operator cab with side screens with a minimal inside cab width of 838 mm. Meets SAE-J1040 and ISO 3471 for Roll Over Protective Structure (ROPS) and SAE-J1043 and ISO 3449 Level I \* for Falling Objects Protective Structure (FOPS). Level II \*\* option is available. Use for servicing when lift arms are raised.

Always set brake when leaving loader.

Should always be used when entering/exiting loader.
Slip resistant tread on lift arms and main frame to be used

when entering/exiting loader.

Should always be used when entering/exiting loader.

For emergency exit.

Use for indoor and low light operation.

For use in areas with high traffic

Lift kits are available so loader may be lifted into remote areas

Restricts objects and material from entering cab openings. Weather-resistant operator handbook attached to the inside of the cab, providing operational instructions and warnings decals with pictorials and international symbols.